

6R15

BSB6R15-A0510

セイコーウォッチ株式会社 <http://www.seiko-watch.co.jp/>

お客様相談窓口〔全国フリーダイヤル〕0120-612-911 (下記の最寄地に着信いたします)

お客様相談室

東京 〒101-0044 東京都千代田区鍛冶町 2-1-10

大阪 〒550-0013 大阪市西区新町 1-4-24 大阪四ツ橋新町ビルディング 8階

SEIKO

取扱説明書

I N S T R U C T I O N S

Mechanical Watch

M

この度は弊社製品をお買い上げいただき、
誠にありがとうございました。
ご使用前にこの説明書をよくお読みの上
正しくご愛用くださいますよう、お願い申し上げます。
なお、この説明書はお手元に保管し必要に応じてご覧ください。

※ お買い求めの際の金属バンドの調整はお買い上げ店・弊社お客様相談窓口（裏表紙に記載）にて承っておりますが、その他のお店では有料もしくはお取扱いいただけない場合があります。



警告

取扱いを誤った場合に、重傷を負うなどの重大な結果になる危険性が想定されることを示します。



警告

乳幼児の手の届くところに時計本体や部品を置かないでください

電池や部品を乳幼児が飲み込んでしまうおそれがあります。万一飲み込んだ場合は、身体に害があるため、ただちに医師にご相談ください。



警告

次のような場合、ご使用を中止してください

- 時計本体やバンドが腐食等により鋭利になった場合
- バンドのピンが飛び出してきた場合

※ すぐに、お買い上げ店・弊社お客様相談窓口（裏表紙に記載）にご相談ください



注意

取扱いを誤った場合に、軽傷を負う危険性や物質的損害をこうむることが想定されることを示します。



注意

以下の場所での携帯・保管は避けてください

- 揮発性の薬品が発散しているところ（除光液などの化粧品・防虫剤・シンナーなど）
- 5℃～35℃から外れる温度に長期間なるところ ○ 高湿度なところ
- 磁気や静電気の影響があるところ ○ ホコリの多いところ
- 強い振動のあるところ



注意

アレルギーやかぶれを起こした場合

ただちに時計の使用をやめ、皮膚科など専門医に相談してください。



注意

その他のご注意

- 提げ時計やペンダント時計のひもやチェーンが衣類や手・首などを傷つけるおそれがありますのでご注意ください。
- 商品の分解・改造はしないでください。
- 乳幼児に時計が触れないようにご注意ください。ケガやアレルギーをひき起こすおそれがあります。

目次

操作について

各部の名称	8
ご使用方法	10

ご注意いただきたいこと


アフターサービスについて	20
保証について	22
お手入れについて	24
防水性能について	26
耐磁性能について	30
バンドについて	32
特殊な中留の使い方について	34
ルミブライトについて	40
こんな時には	41
メカニカルウオッチの精度について	42
製品仕様	44

■メカニカルウオッチの特徴（手巻、自動巻）


- この時計は「ゼンマイ」を動力に使用した、メカニカルウオッチです。
- 止まった状態からご使用になるときは、りゅうずを20回位手で巻いてゼンマイを巻き上げてから始動させてください。
- 精度はクォーツウオッチが月差・年差であるのに対し、メカニカルウオッチは日差（一日あたりの進み・遅れ）となります。
- さらに、ご使用になる条件（携帯時間、温度、腕の動き、巻き上げ量等）によって微妙に影響を受けますので、誤差は一定ではありません。
- 外部から強い磁気の影響を受けますと、一時的に精度がズレることがあります。影響の度合いによっては、部品が磁化してしまうことがあります。その場合は、磁気抜き等の修理が必要となりますので、お買い上げ店にご依頼ください。

操作について

各部の名称



りゅうずをご確認ください



※ りゅうずが誤って引き出される事を防止するため、時計本体にねじ止めできるりゅうずです。

- 時計の操作後は必ずりゅうずを押し付けながら右に回して元通りに締めてください。
- りゅうずを締める時、回しにくい場合は元に戻してからやり直してください。
- 無理に締めますとねじを壊す恐れがあります。

ご使用方法

ゼンマイの巻き方

- 1.この時計は、自動巻き式機械時計（手巻き付き）です。
- 2.ゼンマイは時計を腕につけた状態では通常の腕の動きで自然に巻くことができます。またりゅうずを回してもゼンマイを巻くこともできます。
- 3.止まっている時計をお使いになるときは、時計を振っても動き出しますが、りゅうずをまわしゼンマイが十分に巻かれた状態にしまして、日付けと時刻を合わせてから腕にお付けください。ゼンマイを巻く際には、りゅうず0段位置で右回転方向に（12時方向）にゆっくりとまわしてください。なお、りゅうずは左方向（6時方向）では空回りするようになっています。また、ゼンマイはフル巻上げ状態でゼンマイがスリップするようになっており、ゼンマイを切る心配はありません。
- 4.ゼンマイが十分に巻き上げられた状態での可動時間は約50時間です。

- ※ゼンマイの巻き上げ量が不足しますと進み遅れの原因になりますので、1日10時間以上携帯することをお勧めします。また、時計を腕につけないでご使用される場合は、毎日一定の時刻にりゅうずをまわしゼンマイを十分に巻いてご使用ください。
- ※ゼンマイが解けて止まった状態からお使いの場合、リュウズでゼンマイを巻き上げても直ぐには動きません。機械式時計の特徴でゼンマイ巻き始めのゼンマイトルク（力）が弱いためです。ゼンマイが巻かれてある程度の強いトルクに達すると秒針が動き始めますが、早めに動かすためには、時計を振りテンプを強制的に回転させることで動かすことができます。

時刻・日付けの合わせ方


この時計には、日付表示機能がついています。24時間に1回日付を一日分送るようになっています。日付は、「午前0時」ごろ送るようになっています。よって、午前午後をまちがえて時刻合わせをしてしまいますと、お昼の「12」時ごろに日付が変わってしまいます。

⚠️ ご注意

- 時刻表示が午後10時から午前1時までの間、日付の修正をしないでください。この時間帯に日付を修正しますと、翌日になっても日付が切り変わらないことや、故障の原因となる場合があります。

- ①りゅうずを1段目まで引き出してください。
- ②りゅうずを回転することで日付の修正ができます。前の日の日付に合わせます。

(例) 合わせる日付が「6日」の場合、「5日」に合わせます。
左回転(6時方向)に回すことで日付合わせが行えます。




③りゅうずを2段目まで引き出します。

秒針が「12時」の位置に来たときに引き出してください。(秒針が止まります。)
りゅうずを回転させ、針が進む方向にまわし、日付が今日の日付になるまでまわしてください。日付が変わると「午前」です。さらに進めて現在の時刻に合わせます。

④時報と同時にりゅうずを0段目まで押し込むと動き出します。

※時刻合わせは、電話の時報サービスTEL.117が便利です。



⚠️ ご注意


○当キャリバーは輪列機構上から時刻を合わせる際には、針をいったん正しい時刻よりやや遅らせておき、それから進めて合わせるようにしてください。

月末の日付修正について

2月（1カ月が28日、うるう年は29日）と小の月（1カ月が30日）では日付の修正が必要になります。

【例】小の月の翌月1日の朝、日付を修正する場合

「1日」ではなく「31日」が表示されています。りゅうずを1段目に引き出してください。りゅうずを左回転させ、日付を「1日」に合わせ、りゅうずを押し込んでください。



⚠️ ご注意

- 時刻表示が午後10時から午前1時までの間、日修正は避けてください。故障の原因になります。

ご注意ください

アフターサービスについて

修理用部品について

- この時計の修理用部品の保有期間は通常7年間を基準としています。
- 修理の際、一部代替部品を使用させていただくことがありますのでご了承ください。

オーバーホール(分解掃除)について

時計は精密機械です。部品の油切れや磨耗により止まり遅れが生じることがあります。その際にはオーバーホールをご依頼ください。

保証と修理について

- 修理やオーバーホールの際は、お買い上げ店・弊社お客様相談窓口にご相談ください。
- 保証期間内の場合は必ず保証書を添えてください。
- 保証内容は保証書に記載したとおりです。よくお読みいただき大切に保管してください。

保証について

取扱説明書にそった正常な使用により、お買い上げ後1年以内に不具合が生じた場合には、下記の保証規定によって無料で修理・調整いたします。

保証の対象部分

- 時計本体（ムーブメント・ケース）及び金属バンドです。

保証の適用除外（保証期間内あるいは保証対象部分であっても、次のような場合には有料になります）

- 皮革・ウレタン・布等のバンドの交換
- 事故または不適切な取扱いによって生じた故障および損傷
- ご使用中に生じるキズ・汚れ等
- 火災・水害・地震等の天災地変による故障及び損傷
- 保証書記載項目の全てが記入された保証書のみが有効です。故意に字句を書き換えた場合は規定の無償修理は受けられません。

保証は、保証書に明示した期間・条件のもとにおいて、無料修理をお約束するものです。これによりお客様の法律上の権利を制限するものではありません。保証書は日本国内のみ有効です。

保証を受ける手続き

- 保証対象の不具合が生じた場合は、時計と別紙保証書をご持参の上、お買い上げ店にご依頼ください。
- お買い上げ店の保証が受けられない場合には、「セイコーウォッチ株式会社 お客様相談窓口」に保証書を添えてご依頼ください。

その他

- 修理のとき、ムーブメントを交換させていただいたり、ケース・文字板・針・ガラス・バンドなどに、一部代替部品を使用させていただくこともありますので、ご了承ください。ご使用部品の保有期間は本取扱説明書（P.20）をご参照ください。
- 金属バンド等の調整は、お買い上げ店または弊社お客様相談窓口にご依頼ください。上記以外の販売店での調整は有料になります。

お手入れについて


日頃からこまめにお手入れしてください

- 水分や汗、汚れはこまめに柔らかい布で拭き取るように心掛けてください。
- すきま（金属バンド、りゅうず周り、裏ぶた周りなど）の汚れは柔らかい歯ブラシが有効です。
- 海水に浸けた後は、必ず真水でよく洗ってから拭き取ってください。
その際、直接蛇口から水をかけることは避け、容器に水をためるなどしてから洗ってください。

りゅうずは時々回してください

- りゅうずの錆び付きを防止するために、時々りゅうずを回してください。
- ねじロック式りゅうずの場合も同様です。（りゅうずを引く必要はありません）

時計の裏ぶたでも性能の確認ができます ※下記以外にも様々な種類があります




※上記の図は例であり、お買い上げいただいた時計とは異なります。

防水性能について

お買い上げいただいた時計の防水性能を
下記の表でご確認の上で使用ください。
(「P.25」をご覧ください)

裏ぶた表示	防水性能
表示なし	非防水です。
WATER RESISTANT	日常生活用防水です。
WATER RESISTANT 5 BAR	日常生活用強化防水で5気圧防水です。
WATER RESISTANT 10(20) BAR	日常生活用強化防水で10(20)気圧防水です。

お取扱方法
水滴がかかったり、汗を多くかく場合には、使用しないで下さい。
日常生活での「水がかかる」程度 の環境であれば使用できます。  警告 水泳には使用しないで下さい。
水泳などのスポーツに使用できます。
空気ボンベを使用しないスキンドайビングに使用できます。

⚠ 警告



この時計はスキューバダイビングや飽和潜水には絶対に使用しないで下さい

BAR (気圧) 表示防水時計はスキューバダイビングや飽和潜水用の時計に必要なとされる苛酷な環境を想定した様々な厳しい検査を行っていません。専用のダイバースウオッチをご使用下さい。

⚠ 注意

※ 万一、ガラス内面にくもりや水滴が発生し、長時間消えない場合は防水不良です。お早めに、お買い上げ店・弊社お客様相談窓口(裏表紙に記載)にご相談ください。



水分のついたまま、りゅうずやボタンを操作しないで下さい

時計内部に水分が入ることがあります。

⚠ 注意



水や汗、汚れが付着したままにしておくのは避けて下さい

防水時計でもガラスの接着面・パッキンの劣化や、ステンレスが錆びることにより、防水不良になる恐れがあります。



入浴やサウナの際はご使用を避けてください

蒸気や石けん、温泉の成分などが防水性能の劣化を早めてしまうからです。




直接蛇口から水をかけることは避けてください

水道水は非常に水圧が高く、日常生活用強化防水の時計でも防水不良になる恐れがあります。

耐磁性能について (磁気の影響)

アナログクォーツ時計は、身近にある磁気の影響を受け、時刻が狂ったり止まったりします。

※磁気により時刻が狂っても、遠ざければ正常に動きます。時刻を合わせ直してお使いください。

裏ぶた表示	お取扱方法
表示なし	磁気製品より10cm以上遠ざける必要があります。
	磁気製品より5cm以上遠ざける必要があります。 (JIS水準1種)
	磁気製品より1cm以上遠ざける必要があります。 (JIS水準2種)

時計に影響を及ぼす身の周りの磁気製品例



携帯電話(スピーカー部)

磁気健康バンド

バッグ(磁石の止め金)

磁気ネックレス

交流電気かみそり

磁気健康マット



携帯ラジオ(スピーカー部)

磁気健康枕

電磁調理器

など

アナログクォーツ時計が
磁気の影響を受ける理由

内蔵されているモーターは磁石を使用しており、外からの強い磁力で互いに影響し合い、モーターを止めたり、無理に回転させてしまうためです。

バンドについて

バンドは直接肌に触れ、汗やほこりで汚れます。

そのため、手入れが悪いとバンドが早く傷んだり、肌のかぶれ・そで口の汚れなどの原因になります。長くお使いになるためには、こまめなお手入れが必要です。

金属バンド

- ステンレスバンドも水・汗・汚れをそのままにしておくとさび易くなります。
- 手入れが悪いかぶれやワイシャツの袖口が黄色や金色に汚れる原因になります。
- 水や汗・汚れは、早めに柔らかな布で取り除いてください。
- バンドのすき間の汚れは、水で洗い、柔らかな歯ブラシ等で取り除いてください。
(時計本体は水にぬれないように台所用ラップなどで保護しておきましょう)

皮革バンド

- 水や汗、直射日光には弱く、色落ちや劣化の原因になります。
- 水がかかった時や汗をかいた後は、すぐに乾いた布などで吸い取るように軽く拭いてください。
- 直接日光にあたる場所に放置しないでください。
- 色味の薄いバンドは、汚れが目立ちやすいので、ご使用の際はご注意ください。

- 時計本体が日常生活強化防水(10気圧防水)になっているものでも、アクアフリーバンド以外の皮革バンドは、入浴中や水泳、水仕事などでのご使用はお控えください。

ポリウレタンバンド

- 光で色が褪せたり、溶剤や空気中の湿気などにより劣化する性質があります。
- 特に半透明や、白色、淡色のバンドは、他の色を吸着し易く、また変色をおこします。
- 汚れたら水で洗い、乾いた布で良く拭き取ってください。
(時計本体は水にぬれないように台所用ラップなどで保護しておきましょう)
- 弾力性がなくなり、ひび割れを生じたら取り替え時期です。

かぶれやアレルギーについて

バンドによるかぶれは、金属や皮革が原因となるアレルギー反応や、汚れもしくはバンドとのすれなど不快感が原因となる場合など、いろいろな発生原因があります。

バンドサイズの目安について


バンドは多少余裕をもたせ通気性をよくしてご使用ください。時計をつけた状態で、指一本入る程度が適当です。




特殊な中留の使い方について

皮革バンド、および、メタルバンドの一部に
特殊な中留を用いたものがございます。
お買い上げの時計の中留が下記のいずれかに当てはまる場合は、
各々の操作方法をご覧ください。

- Ⓐ三ツ折中留(皮革バンド専用) Ⓑワンプッシュ三ツ折中留(皮革バンド、メタルバンド)




- ⒸLUKIALレザーバンド用三ツ折中留(皮革バンド専用)




Ⓐ三ツ折中留(皮革バンド専用)の使い方


- 1) バンドを定革、遊革から抜いて、中留を開きます。




- 2) 上箱の底板を下に開きます。



- 3) ピンをバンドのアジャスト穴から外し、バンドを左右にスライドさせて適切な長さのところでピンをアジャスト穴にもう一度入れます。



- 4) 底板を閉めます。
(底板を押し込みすぎないようにしてください。)




※中留を装着するときは、バンドの剣先(先端)を定・遊革に入れてから、中留をしっかり留めて下さい。

B ワンプッシュミツ折中留（皮革バンド、メタルバンド）の使い方

① 時計の着脱方法

1) 両方のプッシュボタンを押しながらバンドを定革・遊革から抜いて、中留を開きます。

2) バンドの剣先（先端）を定革・遊革に入れてから、上箱の上面位置をしっかり押さえ留めます。




※メタルバンドの場合は、定革がない場合がございます。

② バンドの長さ調整方法


1) 両方のプッシュボタンを押しながらバンドを定革・遊革から抜いて、中留を開きます。

2) もう一度プッシュボタンを押し上箱を下に開きます。




③レザーバンド用三ツ折中留の使い方


- 3) ピンをバンドのアジャスト穴から外し、バンドを左右にスライドさせて適切な長さのところでピンをアジャスト穴に入れます。




- 4) プッシュボタンを押しながら上箱を閉めます。



- 1) プッシュボタンを押しながら中留を開きます。



- 2) バンドのアジャスト穴をピンから外し、バンドを左右にスライドさせて適切な長さのところでピンをアジャスト穴にもう一度入れ、プッシュボタンを押しながら中留をしっかりと抑え留めます。



ルミブライトについて

〔お買い上げの時計がルミブライトつきの場合〕

ルミブライトは、放射能等の有害物質を全く含んでいない、環境・人に安全な蓄光（蓄えた光を放出する）物質です。

ルミブライトは、太陽光や照明器具の明かりを短時間（10分間:500ルクス以上）で吸収して蓄え、暗い中で長時間（約3～5時間）光を放つ夜光です。なお、蓄えた光を発光させていますので、輝度（明るさ）は時間が経つに従ってだんだん弱まってきます。また、光を蓄える際のまわりの明るさや時計との距離、光の吸収度合いにより、光を放つ時間には多少の誤差が生ずることがあります。

〈照度データ〉（目安値）

- | | | |
|------------------|----------------------|---------------------|
| ①太陽光 | [晴天] 100,000ルクス | [曇天] 10,000ルクス |
| ②屋内（昼間窓際） | [晴天] 3,000ルクス以上 | [曇天] 1,000～3,000ルクス |
| | [雨天] 1,000ルクス以下 | |
| ③照明（白色蛍光灯40Wの下で） | [1m] 1,000ルクス | |
| | [3m] 500ルクス（通常室内レベル） | |
| | [4m] 250ルクス | |

こんな時には

現象	考えられる原因	このようにしてください
時計が止まった。	ゼンマイが巻かれていない。	ゼンマイを手で巻くか、または数回振れば動き出します。 それでも、動かない場合は、お買い上げ店にご相談ください。
時計が一時的に進む／遅れる。	暑いところまたは寒いところに長く置いた。	精度は、常温にもどれば元にもどります。
	磁気を発生するもののそばに置いた。	精度は、磁気の発生するものから放せば元にもどります。 元にもどらない場合は、お買い上げ店にご相談ください。
	落としたり強くぶつけたり、または激しいスポーツをした。 強い振動が加えられた。	精度は、元にもどりません。お買い上げ店にご相談ください。
	3年を越える長期間、分解掃除による点検調整を行っていない。	お買い上げ店にご相談ください。
日付が日中に変わる。	時刻合わせが違っている。	12時間分、針を進めてください。
ガラスのくもりが消えない。	パッキンの劣化などにより時計内部に水分が入った。	お買い上げ店にご相談ください。

※その他の現象は、お買い上げ店にご相談ください。

メカニカルウォッチの精度について

- メカニカルウォッチの精度は「日差」です。
- メカニカルウォッチの精度は時計の姿勢（向き）によって、進み／遅れ具合が変わり、またお客様のご使用になる条件（携帯時間・温度・腕の動き・ぜんまいの巻き上げ量など）により、所定の精度の範囲を超える場合があります。
- 1日のみの誤差で判断せず1週間程度の誤差で判断するようにしてください。
- 精度の温度差
 - ・メカニカルウォッチの精度を作る部分には金属が使われています。金属の特性として、温度の変化によって伸び縮みすることは良く知られています。これが時計の精度に影響を与えます。メカニカルウォッチは高温下では遅れがちになり低温下では進みがちになります。

○ぜんまいの巻き具合と精度

精度を高めるためには、歯車の速度をコントロールするテンプに規則正しくエネルギーを補給する事が重要です。メカニカルウォッチの動力源であるぜんまいは、いっぱいに巻かれている状態とほどける直前の状態では力が異なり、ほどけるにしたがって力が弱くなっていきます。

自動巻き式は頻繁に携帯していただく事で、また手巻き式はぜんまいを毎日一回一定の時刻に十分に巻き上げて規則正しく動かす事で、比較的安定した精度が得られます。

○磁気の影響

外部から強い磁気の影響を受けると、一時的に精度がズれることがあります。影響の度合いによっては、部品が磁化してしまう事があります。

その場合は磁気抜き等の修理が必要となりますので、お買い上げ店にご依頼ください。

製品仕様

機 種	6R15
1.機 能	3針 時間表示(時針、分針、秒針)・日表示
2.振 動 数	21,600振動/時間
3.精 度	日差 +25秒~-15秒 (常温5°C~35°Cにおいて)
4.駆動方式	ゼンマイ巻(自動巻き<手巻き付>)
5.使用石数	23石

※上記精度は工場出荷時に調整されたものです。

※メカニカルウオッチの特性上、ご使用になる条件(携帯時間、温度、腕の動き、ゼンマイの巻き上げ量など)によっては上記精度の範囲を超える場合があります。

Thank you very much for choosing a SEIKO watch.
For proper and safe use of your SEIKO watch,
please read carefully the instructions
in this booklet before using.

Keep this manual handy for easy reference.

※Length adjustment service for metallic bands is available at the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER (listed on the back cover). The service may also be available on a chargeable basis at other retailers, however, some retailers may not undertake the service.

WARNING

To indicate the risks of serious consequences such as severe injuries unless the following safety regulations are strictly observed.



WARNING

Keep the watch and accessories out of the reach of babies and children.

Care should be taken to prevent a baby or a child accidentally swallowing the battery or accessories.
If a baby or child swallows the battery or accessories, immediately consult a doctor, as it will be harmful to the health of the baby or child.



WARNING

Immediately stop wearing the watch in following cases.

- If the watch body or band becomes edged by corrosion etc.
- If the pins protrude from the band.

※ Immediately consult the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER (listed on the back cover).

CAUTIONS

To indicate the risks of light injuries or material damages unless the following safety regulations are strictly observed.



CAUTIONS

Avoid the following places for wearing or keeping the watch.

- Places where volatile agents (cosmetics such as polish remover, bug repellent, thinners etc.) are vaporizing
- Places where the temperature drops below 5 °C or rises above 35 °C for a long time
- Places of high humidity
- Places affected by strong magnetism or static electricity
- Dusty places Places affected by strong vibrations



CAUTIONS

If you observe any allergic symptoms or skin irritation

Stop wearing the watch immediately and consult a specialist such as a dermatologist or an allergist



CAUTIONS

Other cautions

- Note that there is a risk of damaging your clothes, hand or neck with the band, cord or chain of the pocket watch or pendant watch.
- Do not disassemble or tamper with the watch.
- Keep the watch out of the reach of babies and children. Extra care should be taken to avoid risks of any injury or allergic rash or itching that may be caused when they touch the watch.

C O N T E N T S [目 次]

HOW TO USE


Names of the parts	52
How to use	54

TO PRESERVE THE QUALITY OF YOUR WATCH


After- Sale service	64
Guarantee	66
Daily care	68
Water resistance	70
Magnetic resistance	74
Band	76
Special Clasps	78
Lumibrite	84
Trouble shooting	85
Accuracy of Mechanical Watches	86
Specifications	88

HOW TO USE

Names of the parts



Check the type of the crown of your watch



※ This type of crown can be screwed into the watch body to avoid being pulled out by mistake.

- After completing all settings of the watch, screw the crown in again by turning it clockwise while pressing it.
- If the crown turns out to be too stiff to be screwed up, turn the crown counterclockwise once and then give another try.
Do not screw it in by force as it may damage the slots of the crown.

How to use

How to use the automatic mechanical watch

- This is an automatic mechanical watch with manual winding mechanism.
- When the watch is worn on the wrist, the mainspring is wound automatically through normal wrist movement.
- The watch can also be wound up by turning the crown. To do so, unscrew the crown by turning it counterclockwise.
- To start the watch after it stops completely, wind it up either by turning the crown or swinging it from side to side until the second hand starts moving. Then, set the time and date before putting the watch on the wrist.
- To wind up the watch, unscrew the crown by turning it counterclockwise, and then, turn it clockwise slowly. The watch cannot be wound by turning the crown counterclockwise.

- The watch is wound up fully. (Turning the crown further will not break the spring) Once the watch is wound up fully, it operates for about 50 hours.
- If the watch is used without being wound up fully, gain or loss of the watch may result. To avoid this, wear the watch for more than 10 hours a day. If the watch is used without wearing on the wrist; if it is used on the desk like a clock, for example; be sure to wind it up fully every day at a fixed time.
- If you use a watch that has stopped with the mainspring unwound, winding the mainspring with the crown will not start the watch immediately. That is because the mainspring torque (force) is low at the beginning of its winding due to the characteristics of mechanical watches. The second hand starts to move when a certain degree of strong torque is reached after the mainspring has been wound up. However, swinging the watch from side to side to forcibly turn the balance can start the watch sooner.


How to set the time and date

- Check that the watch is operating, and then, set the time and date.
- The watch is provided with a date function and is so designed that the date changes once every 24 hours. The date changes around 12 o'clock midnight. If AM/PM is not properly set, the date will change at 12 o'clock noon.

① Pull out the crown to the first click. (The second hand continues moving.)

② The date can be set by turning the crown counterclockwise. Turn it until the previous day's date appears.

Ex.) If today is the 6th of the month, first set the date to "5" by turning the crown clockwise.




⚠ CAUTION

- Do not set the date between 10:00 p.m. and 1:00 a.m. Otherwise, the date may not change properly.

- ③ Pull out the crown to the second click when the second hand is at the 12 O'clock position. (The second hand stops on the spot.)
Turn the crown to advance the hands until the date changes to the next. The time is now set for the A.M. period. Advance the hands to set the correct time.

- ④ Push the crown back in to the normal position in accordance with a time signal.

※ The telephone time signal service is helpful for setting the second hand exactly.



⚠ CAUTION


- The mechanism of mechanical watches is different from that of quartz watches.
When setting the time, be sure to turn back the minute hand a little behind the desired time and then advance it to the exact time.

Date adjustment at the end of the month

It is necessary to adjust the date at the end of February and 30-day months.

Ex.) To adjust the date in the A.M. period on the first day of a month following a 30-day month>

- (1) The watch displays "31" instead of "1". Pull out the crown to the first click.
- (2) Turn the crown to set the date to "1" and then push the crown back in to the normal position.



⚠ CAUTION

- Do not set the date between 10:00 p.m. and 1:00 a.m. as this will cause a malfunction.

TO PRESERVE THE QUALITY OF YOUR WATCH

After-sale service

Repair parts

- The repair parts of this watch will be retained usually for 7 years.
- Some alternative parts may be used for repair if necessary.

Notes on overhaul

The watch is a precision device. If the parts run short of the oil or get worn out, the watch may stop its operation or lose time. In such a case, have the watch overhauled.

Notes on guarantee and repair

- Contact the retailer the watch was purchased from or SEIKO CUSTOMER SERVICE CENTER for repair or overhaul.
- Within the guarantee period, present the certificate of guarantee to receive repair services.
- Guarantee coverage is provided in the certificate of guarantee. Read carefully and retain it.

Guarantee

Within one year from the date of purchase, we guarantee free repair/adjustment service against any defects according to the following guarantee regulations, provided that the watch was properly used as directed in this instruction booklet.

Guarantee coverage

- The watch body (movement·case) and metallic band.

Exceptions from guarantee

In following cases, repair/adjustment services will be at cost even within the guarantee period or under guarantee coverage.

- Change of leather/urethane/cloth band
- Troubles or damage caused by accidents or improper usage
- Scratches or grime caused by use
- Problems and damage caused by acts of god, natural disasters including fire, floods or earthquakes.
- The certificate of guarantee is valid only if all the necessary items are properly filled in. We will not honor an altered or tampered certificate of guarantee for free repair services.

Free repair services are guaranteed only under the period and conditions specified in the certificate of guarantee. It does not affect specific legal rights of a consumer.

The certificate of guarantee is valid only in Japan.

Procedure to claim free repair services

- For any defects under guarantee, submit the watch together with the attached certificate of guarantee to the retailer from whom the watch was purchased.
- If repair services cannot be provided by the retailer from whom the watch was purchased, contact SEIKO CUSTOMER SERVICE CENTER. In this case, the attached certificate of guarantee is also needed.

Others

- The case, dial, hands, glass and bracelet, or parts thereof may be repaired with substitutes if the originals are not available. If necessary, movements will be replaced.
- For length adjustment service of a metallic band, ask the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER. Other retailers may undertake the service on a chargeable basis.

Daily care


The watch requires good daily care

- Wipe away moisture, sweat or dirt with a soft cloth
- To clean the clearances (around the metallic band, crown or case back), a soft toothbrush is convenient.
- After soaking the watch in seawater, be sure to wash the watch in clean pure water and wipe it dry carefully.

Turn the crown from time to time

- In order to prevent corrosion of the crown, turn the crown from time to time.
- The same practice should be applied to a screw lock type crown.
(No need to pull out the screw lock type crown.)

The case back shows the caliber and performance of your watch




※The figure above one example. Performance of your watch is different from above sample.

Water resistance

Refer the table below for the description of each degree of water resistant performance of your watch before using.

(Refer to " P.69 ")

Indication on the case back	Water resistant performance
No indication	Non-water resistance
WATER RESISTANT	Water resistance for everyday life
WATER RESISTANT 5 BAR	Water resistance for everyday life at 5 barometric pressures
WATER RESISTANT 10 (20) BAR	Water resistance for everyday life at 10(20) barometric pressures.

Condition of Use
Avoid drops of water or sweat
The watch withstands accidental contact with water in everyday life.  WARNING Not suitable for swimming
The watch is suitable for sports such as swimming.
The watch is suitable for diving not using an air cylinder.

WARNING



Do not use the watch in scuba diving or saturation diving.

The various tightened inspections under simulated harsh environment, which are usually required for watches designed for scuba diving or saturation diving, have not been conducted on the water-resistant watch with the BAR (barometric pressure) display. For diving, use special watches for diving.

CAUTION

※ If the inner surface of the glass is clouded with condensation or water droplets appear inside of the watch for a long time, the water resistant performance of the watch is deteriorated. Immediately consult the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER (listed on the back cover).



Do not turn or pull out the crown when the watch is wet.

Water may get inside of the watch.

CAUTION



Do not leave moisture, sweat and dirt on the watch for a long time.

Be aware of a risk that a water resistant watch may lessen its water resistant performance because of deterioration of the adhesive on the glass or gasket, or the development of rust on stainless steel.



Do not wear the watch while taking a bath or a sauna.

Steam, soap or some components of a hot spring may accelerate the deterioration of water resistant performance of the watch.



Do not pour running water directly from faucet.



The water pressure of tap water from a faucet is high enough to degrade the water resistant performance of a water resistant watch for everyday life.

Magnetic resistance (affect of magnetic field)

Affected by nearby magnetism,

a quartz watch may temporarily gain or lose time or stop operating.

※This defective condition caused by magnetism will be corrected soon after the watch is removed from the magnetic source. Reset the time once again before using the watch.

Indication on the case back	Condition of use
No indication	Keep the watch more than 10 cm away from magnetic products.
	Keep the watch more than 5 cm away from magnetic products. (JIS level-1 standard)
	Keep the watch more than 1 cm away from magnetic products. (JIS level-2 standard)

Examples of common magnetic products that may affect watches



Cellular phone (speaker)



Bag (with magnet buckle)

AC-powered shaver



Portable radio (speaker)



Magnetic cooking device etc

Magnetic health belt

Magnetic necklace

Magnetic health mat

Magnetic health pillow

The reason why analogue quartz watch is affected by magnetism.

It is because the built-in motor of the watch, which harnesses magnetic power and external strong magnetism, affect each other to stop the motor or suppresses the turn of the motor.

Band (maintenance procedure)

The band touches the skin directly and becomes dirty with sweat or dust. Therefore, lack of care may accelerate deterioration of the band or cause skin irritation or stain on the sleeve edge. The watch requires a lot of attention for long usage.

Metallic band

- Moisture, sweat or soil will cause rust even on a stainless steel band if they are left for a long time.
- Lack of care may cause a yellowish or gold stain on the lower sleeve edge of shirts.
- Wipe off moisture, sweat or soil with a soft cloth as soon as possible
- To clean the soil around the joint gaps of the band, wipe it out in water and then brush it off with a soft toothbrush.
(Protect the watch body from water splashes by wrapping it up in plastic wrap etc.)

Leather band

- A leather band is susceptible to discoloration and deterioration from moisture, sweat and direct sunlight.
- Wipe off moisture and sweat as soon as possible by gently blotting them up with a dry cloth.

Polyurethane band

- A polyurethane band is susceptible to discoloration from light, and may be deteriorated by solvent or atmospheric humidity.
- Especially a translucent, white, or pale colored band easily adsorbs other colors, resulting in color smears or discoloration.
- Wash out dirt in water and clean it off with a dry cloth.
(Protect the watch body from water splashes by wrapping it up in plastic wrap etc.)
- When the band becomes less flexible or cracked, replace the band with a new one.

Notes on skin irritation and allergy

Skin irritation caused by a band has various reasons such as allergy to metals or leathers, or skin reactions against friction on dust or the band itself.

Notes on the length of the band


Adjust the band to allow a little clearance with your wrist to ensure proper airflow. When wearing the watch, leave enough room to insert a finger between the band and your wrist.




Special Clasps

A Type


There are 3 type of special clasps as described below;
If the clasp of the watch you purchased is one of them,
please refer to the indications.




1) Lift up the clasp to release the buckle.




2) Open the flap.



3) Take the pin out of the adjustment hole, adjust the size of the strap by sliding it back and forth, and then put the pin back into the appropriate adjustment hole.



4) Close the flap.





B Type

① How to wear or take off the watch

- 1) Press the button on both sides of the buckle ; pull the buckle up. The band will automatically come out of the loop.

- 2) Place the tip of the band into the moveable loop and fixed loop, and fasten the clasp by pressing the frame of the buckle.





※No Fixed loop with Metal Bracelets.


② How to adjust the length of the leather band

- 1) With pressing buttons on both sides of the buckle, pull the leather band out of the moveable loop and fixed loop. Then open the clasp.


- 2) Press the push buttons again to unfasten the buckle.




- 3) Pull the pin out of an adjustment hole of the band. Slide the band to adjust its length and find an appropriate hole. Place the pin into the hole.




- 4) Fasten the buckle with pressing the push buttons.



- 1) Press the button on the buckle, and lift to open the clasp.



- 2) To adjust : Pull the pins out of the adjustment holes on the band. Slide the band to the appropriate length. Push the pins into the new holes on the band.



LUMIBRITE

[IF YOUR WATCH HAS LUMIBRITE]

LumiBrite is a luminous paint that is completely harmless to human beings and natural environment, containing no noxious materials such as radioactive substance.

LumiBrite is a newly-developed luminous paint that absorbs the light energy of the sunlight and lighting apparatus in a short time and stores it to emit light in the dark.

For example, if exposed to a light of more than 500 lux for approximately 10 minutes, LumiBrite can emit light for 5 to 8 hours. Please note, however, that, as LumiBrite emits the light it stores, the luminance level of the light decreases gradually over time. The duration of the emitted light may also differ slightly depending on such factors as the brightness of the place where the watch is exposed to light and the distance from the light source to the watch.

<Reference data on the luminance>

(A) Sunlight

[Fine weather]: 100,000 lux [Cloudy weather]: 10,000 lux

(B) Indoor (Window-side during daytime)

[Fine weather]: more than 3,000 lux [Cloudy weather]: 1,000 to 3,000 lux

[Rainy weather]: less than 1,000 lux

(C) Lighting apparatus (40-watt daylight fluorescent light)

[Distance to the watch: 1m]: 1,000 lux

[Distance to the watch: 3m]: 500 lux (average room luminance) [Distance to the watch: 4m]: 250 lux

TROUBLESHOOTING

Problem	Possible cause	Solution
The watch stops operating.	The watch is not wound up sufficiently.	Turn the crown or swing the watch to wind it up. The watch will start operating. If the watch not, consult the retailer from whom the watch was purchased.
The watch gains/loses temporarily.	The watch has been left in extremely high or low temperatures for a long time.	The normal accuracy will resume when the watch returns to normal temperature.
	The watch was brought into close contact with a magnetic object.	The normal accuracy will resume when the watch is kept away from close contact with the magnetic source. If this condition persists, consult the retailer from whom the watch was purchased.
	You dropped the watch, hit it against a hard surface or wore it while playing active sports. The watch was exposed to strong vibrations.	The normal accuracy will not resume. Consult the retailer from whom the watch was purchased.
	The watch has not been overhauled for more than 3 years.	Consult the retailer from whom the watch was purchased.
The date changes at 12 o'clock noon.	AM/PM is not properly set.	Advance the hands by 12 hours.
The glass is blurred and the blur persists for a long time.	Water got inside the watch due to the deterioration of the gasket, etc.	Consult the retailer from whom the watch was purchased.

※For the solution of troubles other than listed above, contact the retailer from whom the watch was purchased. 85

Accuracy of Mechanical Watches

- The accuracy of mechanical watches is indicated by the "daily rate."
- The accuracy of mechanical watches may not fall within the specified range of time accuracy because loss/gain changes due to the position of the watch, which is dependent on the conditions of use, such as the length of time during which the watch is worn on the wrist, arm movement, and whether the mainspring is wound up fully or not, etc.
- The loss/gain of mechanical watches is not measured by a daily rate, but by daily rates of one week or so.
- **Accuracy variation according to temperature**
The parts that compose the accuracy of mechanical watches are made of metals. It is well known that metals expand or contract depending on temperatures due to metal properties. This exerts an effect on the accuracy of the watches. Mechanical watches tend to lose time at high temperatures while they tend to gain time at low temperatures.

- **Mainspring wound condition and accuracy**
In order to improve accuracy, it is important to regularly supply energy to the balance that controls the speed of the gears. The driving force of the mainspring that powers mechanical watches varies between when fully wound and immediately before it is unwound. As the mainspring unwinds, the force weakens.
Relatively steady accuracy can be obtained by wearing the watch on the wrist frequently for the self-winding type and winding up the mainspring fully everyday at a fixed time to move it regularly for the wind-up mechanical type.
- **Effect of magnetism**
When affected by a strong magnetism from outside, the mechanical watch may lose/gain time temporarily. The parts of the watch may become magnetized depending on the extent of the effect. In such a case, consult the retailer from whom the watch was purchased since the watch requires repair including demagnetizing.

SPECIFICATIONS

Cal.	6R15
1.Function	3 hands Time display (Hour, minute and second hands),date display
2.Vibrations per hour	21,600
3.Loss/gain (daily rate)	+25 -15seconds at normal temperature range (5°C and 35°C)
4.Driving system	Automatic winding type with manual winding mechanism
5.Jewels	23 jewels

Note: The accuracy above is factory-adjusted.

Note: Due to the characteristics of mechanical watches, any actual daily rate may not fall within the range of time accuracy specified above dependent on the conditions of use, such as the length of time during which the watch is worn on the wrist, temperature, arm movement, and whether the mainspring is wound up fully or not, etc.